



# Harmar®

## AL435 Axis III / 3-Axis Inside Lift

Adjustable arm angle that folds for additional storage

Powered Boom

Adjustable post height

Compact here



Hand-held push button controls



Offset deck base bolts to the floor of your vehicle's trunk or cargo area

**Fits on Most Vehicles!**

### FEATURES

- Provides 200° of rotation to position your scooter or power wheelchair on the sidewalk next to your vehicle
- Manual rotation release in case of power failure
- Adjustable arm angle that folds for additional storage
- Powered boom
- Can be used on vehicles with tailgates
- The offset arm provides clearance around the vehicle opening
- Adjustable limit switches assure accurate, dependable swing control
- Backup mechanical stops prevent rotation over-travel
- Attractive, durable black & metallic gray powder coated finish

### SPECIFICATIONS

Maximum Lifting Capacity:	400 pounds
Weight of Lift:	114 pounds
Maximum Lifting Height:	39" at Horizontal Boom Position
Minimum Lifting Height:	31" at Horizontal Boom Position
Range of Boom Adjustment:	12" Powered from 21" to 33"
Arm Angle Adjustment:	5° Increments from Horizontal to 35+
Column Rotation:	180° Adj. at +/- 20° Increments
Base Leg Adjustment:	180° Total Adjustment

### DESCRIPTION

The AL435 adds a powered boom with 12" of additional reach required to clear the rear bumper of larger vehicles, as well as handle the largest possible power chair or scooter into the smallest vehicle openings. The AL435 offers the ergonomic hand control and two wireless key fobs.

More versatile and flexible than any other inside van and pick-up truck lift on the market today. Adapts to most mini-vans, full sized vans, SUV's and pick-up trucks. Fits other specialty vehicles such as the Chrysler PT Cruiser.